

## CURRENT TIME SETTING

## HAND FACTORY POSITION ADJUSTMENT



Button A      Button B

\*\*If you find that the "watch hand" is out of alignment after the adjustment, please complete "Setting 2". ("Hand Setting Factory Position Adjustment), and then repeat "Setting 1" ("Basic Adjustment Time Setting").

### Setting 1

#### Minute hand setting:

Press and hold the A and B keys for about 3 seconds, the "minute hand" will generate a vibrating signal, at this moment you can adjust the "minute hand" to adjust the A/B key forward or backward to the current time.

#### Hour hand setting:

Press and hold the A button and B button for about 3 seconds, the "minute hand" will vibrate as signal, then press the A and B buttons repeatedly, the "hour hand" will vibrate as signal, at this moment you can adjust the "hour hand" to adjust the A/B button forward or backward to the current time.

#### Day of the week setting:

Press and hold the "A" and "B" buttons for about 3 seconds, the "minute hand" will generate a vibrating signal, then press the "A" and "B" buttons repeatedly until the day of the week hand generates a vibrating signal. (Note: The day hand may jump to the next day at noon of the day, so fasten the hour hand for 12 hours)

### Setting 2

Press and hold the "A" and "B" keys for about 10 seconds, all the hands will return to the default position. make sure the hands show the following factory standard:

- "hour hand" is 0:00
- "Minute hand" is 00 minutes
- "day" hand is SU
- If it is on the right position, wait 5 seconds for the watch to return to the normal time mode.

1. If the above hands are not in the factory set position, press the "A" key and "B" key again for about 10 seconds.
2. The "day hand" will vibrate signal, at which point you can use the "A" button or the "B" button to return to the factory set "SU".
3. When the "day hand" has been adjusted, press the "A" and "B" buttons repeatedly, the "minute hand" will vibrate as signal, at this moment you can use the "A" button or "B" button to return to the factory standard "00".
4. After the "minute hand" is adjusted, press the "A" and "B" keys repeatedly, the "hour hand" will vibrate as signal, and then you can use the "A" key or "B" key to return to the factory.
5. After completing the above actions, you can return to setting 1 and set the time to local time to finish.